


Installation Guide

8mm Corner Entry



Before you Start



Please read this Installation Guide fully. Although these instructions are comprehensive we always recommend that a technically competent installer undertake the installation, as incorrect fitting will invalidate the guarantee.

Unpack with care and check that the enclosure is the correct colour, size, shape and type you require. Ensure that you have all the parts listed as supplied and check for any damage. **Do not install if you are not satisfied** and contact your local supplier.



Important

Ensure the location where you wish to fit the enclosure is suitable. Check there are no electrical cables or pipe work behind the wall. Ensure you have a clean dry area to work within before starting.

The fixings provided for this enclosure are for use on solid walls only. If the enclosure is to be fitted on another type of wall such as plasterboard or stud walls, appropriate fixings should be used and additional tools, fixings or materials may be required.

Ensure that the shower tray installed is level and the walls are vertical, as the enclosure will not sit correctly on an uneven surface. The enclosure can also be used in a wetroom subject to the provision of a periphery area that is flat and level.

Once installed do not use the enclosure for 24 hours to allow the silicone to fully dry.



This product is designed to be used with square trays only. The adjustment on this enclosure is 20mm.



Safety Notes

Please ensure appropriate safety flooring is used as it is normal for spillage to occur when exiting from the shower.

Use safety eyewear and clothing when drilling walls and handling glass. Handle with care, safety glass cannot be re-worked or replaced by ordinary glass.

This product is heavy and requires a 2-person lift.

Keep small parts away from children.



Cleaning

The enclosure must only be cleaned with warm soapy water and a damp cloth or sponge. Abrasive, caustic or scouring products must not be used as these will damage the surfaces of the enclosure.



Technical Help

Technical Service Line: 0845 505 2211 / 01684 293311 Open Mon–Fri 9am–5pm




All dimensions shown are in millimetres unless otherwise stated.

Tools and Materials Required


(not supplied)



Spirit Level




Tape Measure



Screwdriver




Pencil



Power Drill



Suitable Drill Bits



Silicone Sealant



Utility Knife



Safety Eyewear

Parts Supplied


A



Qty 2

Glass Doors
with fitted wheels


B



Qty 2

Straight Glass Panels

C



Qty 2

D




Qty 4

Wall Brackets (ref C)
Profiles (ref D)

Parts Supplied

E



Qty 2

Door Handles
(boxed with allen key)

F



Qty 1

2.5mm Drill Bit (ref F)
12mm Screws (ref G)

G



Qty 8

H



Qty 8


30mm Frame Screws (ref H)
20mm Screws (ref I)

I



Qty 8


J



Qty 8 of each

Rawl Plugs &
30mm Screws


K



Qty 2

Frame Cap R/H & L/H


L



Qty 2


Door Magnets (ref L)
Door Seals (ref M)

M



Qty 2


N



Qty 2

Panel Seals

P



Qty 2

Corner Fixing Joints (ref P)
Corner Fixing Covers (ref Q)

Q



Qty 2

R



Qty 2

Screw Cover Strips (ref R)
Allen Key (ref S)


S



Qty 1

Installation


1



Using a spirit level, check that the shower tray is level and that walls are vertical.


The shower tray must have been fully sealed with silicone sealant at least 24 hours prior to installing enclosure.

2



Drill four evenly spaced holes into the flange side of each wall bracket **C**. These holes will be used for fixing each bracket to the wall. Position the wall brackets onto the shower tray ensuring a distance of 10mm from the front edge of the tray.


3



Using a spirit level, ensure the wall brackets **C** are straight and positioned vertically, then mark the drill positions through the four fixing holes drilled in Step 2.

Note: The flange side of the wall brackets **C (with the four drilled holes) must be positioned on the inner side of the shower tray.**


4



Remove the wall brackets **C** then drill holes in the marked positions on the wall using a 6mm drill bit. Fit the rawl plugs provided **D** (or appropriate fixings for your wall type). We recommend suitable eyewear be worn when drilling walls.

Installation


5



Fix the wall brackets in position using the eight 30mm screws ❶ provided.


Do not over tighten. There should be enough play to allow the screw cover strip ❷ to clip behind the inside (flange) edge of the wall bracket ❸.

6



Take the profiles ❶ and assemble away from the shower tray by securing the straight glass panels ❷ onto the tracks one by one. Secure both tracks and glass together with 30mm frame screws ❸.


7



Lift completed section onto the shower tray between the wall brackets ❸ then adjust ensuring the position is satisfactory.

Note: the wall brackets should be fitted off-set from the door, as shown, with the curved side of the door frame outermost.

8




Adjust the profiles accordingly then connect the corner fixing joints ❹ to secure screens together using the 20mm corner bracket screws ❺.

Take the two corner fixing covers ❻ and clip into position top and bottom.

Installation

9




Adjust the wall brackets **9** until they are evenly overlapped and sit correctly in the space.

Drill three holes in both wall brackets from inside the enclosure using the 2.5mm drill bit **7** as shown, then screw the enclosure assembly through the frame to join to the wall bracket using the six 12mm screws **8**.


Do not over tighten.

10




Take the two glass doors **4**, ensuring the handle holes are in the correct position. Slot the top of the door into the curved wheel track between the door stops and push down on the bottom wheels so they click into the bottom wheel track securely.

11



Some models may be supplied with a top adjustment. If this is the case, the door can be adjusted to make level using the crosshead screw adjusters on the top wheels.

12




Take the magnetic door strips **11** and attach to the glass doors in the middle so they meet.

Attach the short panel seals **11** to the straight panels and the long door seals **11** to the glass doors.


Installation

13



Fit the two screw cover strips ⑩ onto each wall bracket. Clip the cover into the gap between the wall and the wall bracket ⑨ and then clip the opposite side into place. (Any gap between the wall and the wall bracket will be sealed by silicone in Step 16.)


14



Dis-assemble both door handles ③ using the allen key supplied and position through the holes in each glass door. Fit into place, re-assembling in reverse order, and secure the handle with the grub screws using the allen key.

Clip both the frame caps ⑪ into place on top of the wall brackets to complete installation.


15



On the outside of the shower, apply a narrow bead of silicone to the outer edge of the wall brackets ⑨ on both sides.

Follow around the whole of the bottom of enclosure and 25mm up the join of the wall bracket.

16



On the inside on the enclosure, apply silicone vertically where the wall brackets/cover strips meet the wall.

Do not silicone the lower horizontal frame of the enclosure on the inside or the base of the wall brackets or screw cover strips.

You must allow 24 hours for the silicone to dry before use.

Product supplied by the MX Group and/or its subsidiaries

Technical Service Line: 0845 505 2211 / 01684 293311 Open Mon–Fri 9am–5pm